

SETUP INFORMATION FOR WINDOWS NT USERS WITH VXI EMBEDDED CONTROLLERS

Thank you for purchasing a VXI embedded controller from National Instruments. This document contains information about preparing your Windows NT system and where to find a copy of the Windows NT installer should you need to reinstall it.

Logon and Password

You must provide a logon name to receive Windows NT administrator privileges. Log on as *Administrator*. The password is not configured on your unit at this point, so you can just press the <RETURN> key.

After you have successfully logged on to Windows NT, you need to immediately change the password to ensure a secure Windows NT system.

Reinstalling Windows NT

Your VXI embedded controller comes with a copy of the Windows NT installation disks on your hard drive in case you need to reinstall Windows NT. To begin installation, boot from a DOS floppy disk and then type `WINNT /B` from the `C:\IMAGES\OS\WINNT` directory.

The Windows NT operating system on your hard drive has been preinstalled with the latest Windows NT Service Pack. National Instruments recommends you use the latest version available. You can find a copy of the installation disks on your hard drive in the `C:\IMAGES\OS\NTSPx` directory.

Should it be necessary to reinstall the Service Pack, you can either reinstall from the copy on your hard drive or you can download the latest Service Pack version from the Microsoft Corporation World Wide Web site at www.microsoft.com.



321291B-01
January 1997