

TESTSTAND™ RELEASE NOTES

Version 1.0.1

These release notes contain system requirements, installation instructions, new features, and updated information to help you begin using TestStand 1.0.1.

Contents

TestStand Installation.....	2
Minimum System Requirements	2
Installing TestStand	2
What Is New and Different in TestStand 1.0.1	3
New Features	3
Changes to the TestStand 1.0 Database Components	3
Additional Support Information.....	5
Changes to the Getting Started with TestStand Manual	5
Chapter 10—Using ActiveX in Code Modules	5
Changes to the TestStand User Manual	6
Run Mode	6
Chapter 3—Configuring and Customizing TestStand	6
Chapter 4—Sequence Editor Menu Bar	6
Chapter 8—Sequence Context and Expressions.....	7
Chapter 10—Built-In Step Types	8
Chapter 12—Module Adapters	8
Chapter 13—Process Models.....	9
Chapter 15—Run-Time Operator Interfaces	9
Chapter 16—Distributing TestStand	9
Glossary	10
Additional Changes.....	11

TestStand Installation

The TestStand setup program installs TestStand on your computer in approximately 10 minutes.

Minimum System Requirements

To run TestStand for Windows NT/98/95, you must have the following:

- Windows NT 4.0 or later, or Windows 98/95. For Windows NT, National Instruments recommends Service Pack 3 or later.
- At least a 133 MHz Pentium class or higher microprocessor
- SVGA resolution or higher video adapter, with a minimum 800 × 600 video resolution
- Minimum of 64 MB of memory
- 70 MB free hard disk space
- Microsoft-compatible mouse

Installing TestStand



Note National Instruments recommends that you close other applications before you install TestStand.

Follow these instructions to install TestStand:

1. Make sure that your computer and monitor are powered on and that you have installed Windows NT 4.0 or later, or Windows 98/95.
2. Insert your TestStand Installation CD into your CD-ROM drive.
3. Choose **Run** from the **Start** menu.
4. Type `x:\tssetup.exe` in the input box, where *x* is your CD-ROM drive. Click on **OK**.
5. Follow the instructions that appear in the dialog boxes.

National Instruments recommends that you install the complete TestStand program to take full advantage of all the TestStand capabilities. If you choose to install with options, select the options you want and follow the directions on the screen. If necessary, you can run the setup program again later and install additional files.

Refer to the `TestStand\Doc\Readme.txt` file for any additional issues that are too recent to be included in the printed TestStand documentation.

What Is New and Different in TestStand 1.0.1

New Features

TestStand 1.0.1 contains the following new features:

- Multibyte character string support for the localized versions of Windows, for example, Japanese.
- Database Components, which were included in beta form on the TestStand 1.0 CD, are now part of the TestStand installation. See the *Changes to the TestStand 1.0 Database Components* section below for more information and a list of database component changes between TestStand 1.0 and 1.0.1.
- Refer to the `TestStand\Doc\ChangesSince10.txt` file for a complete list of changes and enhancements in TestStand 1.0.1.

Changes to the TestStand 1.0 Database Components

This section describes the changes to the database components between TestStand 1.0 and TestStand 1.0.1.

Custom Data Type Changes

The following changes have been made to the `DatabaseOptions` data type.

- The data type contains a new subproperty, `ConnectionString`. `ConnectionString` defines the data link that the process model uses.
- The data type no longer contains the following properties: `DataSourceName`, `Database`, `UserID`, `Password`, `DatabaseSpecificAttributes`, `IsolationLevel`, `AccessMode`, `ConnectionTimeout`, `CommandTimeout`, `CursorLocation`, and `TransactionAttributes`.

The following changes have been made to the `DatabaseColumnValueList` data type.

- The data type has been renamed to `DatabaseColumnValue`.
- The data type has changed from a custom data type to a standard data type.
- The data type contains two new properties, `WriteNull` and `Status`.



Note The sequence editor automatically converts sequence files that use the above types. You must manually edit any expression that references the renamed or deleted properties.

Step Type Changes

The dynamic link library has been renamed from `Database_32.dll` to `TSDBComponents.dll`.

The following changes have been made to the database component step types:

- **OpenDatabase**—This step type contains a new subproperty, `ConnectionString`. `ConnectionString` defines the data link that the step uses. The following step properties no longer exist: `DataSourceName`, `Database`, `UserID`, `Password`, `DatabaseSpecificAttributes`, `IsolationLevel`, `AccessMode`, `ConnectionTimeout`, `CommandTimeout`, `CursorLocation`, and `TransactionAttributes`.
- **SQLAction**—The descriptive name for the step type has been renamed from `SQLAction` to `DataOperation`. The `ColumnValuesExpression` property has been renamed `ColumnListSource`. The `ColumnValues` property has been renamed `ColumnList`. The property `CacheColumnNumbers` no longer exists. The property `SQLStatement` has been added.



Note The sequence editor automatically converts sequence files that use the above types. You must manually edit any expression that references the renamed or deleted properties.

Database Schema Changes

The following fields in the `STEP_RESULT` default table schema have changed.

- `INTERACTIVE_EXECUTION_NUMBER` has been renamed `INTERACTIVE_EXENUM`.
- `COMPARISON_OPERATOR` has been renamed `COMP_OPERATOR`.
- `SERVER` has been removed.
- `REPORT_TEXT` has been added.



Note You must manually convert the default table schema from TestStand 1.0 to TestStand 1.0.1. Oracle does not allow you to rename fields, so you must create a new column and copy any existing data from the old column to the new column.

Converting Sequences that Use Beta Database Components

TestStand 1.0.1 automatically converts any sequence that uses a beta database component step type or custom data type. If an expression within a sequence references an obsolete property from a TestStand 1.0 database component, you must manually correct the expression.

Additional Support Information

For additional information on TestStand, refer to the National Instruments Web site at www.natinst.com/support/teststand/. The Web site contains many electronic support services such as a KnowledgeBase database, example programs, and software libraries. These resources can help you in your development.

National Instruments also offers an e-mail-based TestStand technical discussion forum. You can join the forum by sending an e-mail to listserv@listserv.tamu.edu with the following text in the body of the note:

```
SUBSCRIBE TESTEXEC <first name> <last name>
```

You will receive an e-mail response with further instructions on sending messages to the forum and unsubscribing from the forum.

Changes to the Getting Started with TestStand Manual

Chapter 10—Using ActiveX in Code Modules

This section describes the changes made to the code module exercises.

Using ActiveX in LabVIEW Test Virtual Instruments

- Add the following paragraph to step 18b on page 10-9:
Do not wire any inputs to the `TestStand - Create Test Data Cluster.vi`. For an Action Step type, TestStand uses only the Report Text terminal. Do not pass the error status to the Pass/Fail flag for any step type.
- Replace step 22h on page 10-11 with the following paragraph:
Add a Waveform Graph indicator and a Dialog button to the VI front panel, as shown in Figure 10-9.



Note Figures 10-9 and 10-10 should display Waveform Graphs rather than XY Graphs.

- Add the following paragraph to step 22i on page 10-12:
Do *not* wire any inputs to the `TestStand - Create Test Data Cluster.vi`. For an Action step type, TestStand uses only the Report Text Terminal. Do not pass the error status to the Pass/Fail flag for any step type.

Changes to the TestStand User Manual

This section contains information on several changes and additions to the *TestStand User Manual*.

Run Mode

Throughout the manual, it is stated that run mode changes made to a step in an execution window apply only to that execution. In fact, these changes apply to all current and new executions until you modify the run mode again in an execution window or a sequence file, or until you reload the sequence file.

Chapter 3—Configuring and Customizing TestStand

Add the following paragraph to the end of the *Modifying the Process Model* section:

Refer to the *TestStand User Manual Addendum* for more information on customizing the information that TestStand logs to a database. You can find the addendum at:

`\TestStand\Doc\TestStandDatabaseComponents.pdf`.

Chapter 4—Sequence Editor Menu Bar

This section describes the changes to the sequence editor menu bar.

Database Options

Add the following section below and at the same level as the *Report Options* section:

The **Database Options** command displays a dialog box in which you can customize the logging of step results and UUT results to a database. The command calls an entry point in the default TestStand process model file. The options you set apply to all sequences you run on the station. Refer to the *TestStand User Manual Addendum* for more information on logging data to a database. You can find the addendum at:

`\TestStand\Doc\TestStandDatabaseComponents.pdf`.

Preferences

The following option was added to the Preferences Tab on the Station Options dialog box:

Prompt to Change System SetForegroundWindow Behavior—On Windows 2000/98 you can configure the operating system so that a test module you run in a process separate from TestStand cannot bring a window to the front when TestStand is active. When your test attempts to bring a window to the front, the window taskbar button blinks to notify the user that another application is attempting to bring a window to the front. During engine initialization, TestStand can detect this system configuration and prompt you for permission to change the system settings to allow your tests to bring their panels to the front. Notice that this is a system setting. Changes to this setting affect the behavior of any application attempting to bring its window to the front when another application window is active.

Disable this option if you do not want TestStand to detect this system configuration. When you disable this option, TestStand does not prompt you, and TestStand does not change your system settings. National Instruments recommends that you enable this checkbox and allow TestStand to change your system settings when you execute test modules in external processes.

This system configuration setting is a DWORD value stored in the registry. The value is `HKEY_CURRENT_USER\Control Panel\Desktop\ForegroundLockTimeout`. This value is the amount of time in milliseconds that a foreground application must be idle (not receiving user input) before the operating system allows a background application to bring its window to the front. The typical value for this setting is `0x7D0` (2,000 ms). TestStand sets the value to zero.

Chapter 8—Sequence Context and Expressions

Add the following property to Table 8-6, The InitialSelection Subproperty in the Sequence Context:

SelectedExecution	Specifies the execution object for the active execution window file when the execution started. This property exists only in the root sequence context and only when an execution window is active at the start of a new execution.
-------------------	---

Chapter 10—Built-In Step Types

Update the introductory text as follows:

This chapter describes the predefined step types that TestStand includes, except for the database step types. Refer to the *TestStand User Manual Addendum* for more information on the built-in database step types. You can find the addendum at:

`\TestStand\Doc\TestStandDatabaseComponents.pdf`.

Chapter 12—Module Adapters

This section describes the changes to the module adapters.

Sequence Adapter

Add the following paragraph to the *Sequence Adapter* section:

You cannot pass an ActiveX Reference as a parameter to a remote sequence unless you configure both machines to have DCOM privileges for accessing each other. Before you can grant DCOM privileges to the remote server, you must configure both the client and the server computer to have user-level access instead of share-level access. If either computer does not have the necessary access privileges, the client computer might display misleading error messages when you pass an ActiveX Reference to the server.

Configuring the ActiveX Automation Adapter

The following options were added to the ActiveX Adapter Configuration dialog box:

- **Run-Time ActiveX Reference Type Checking**—During execution, the Automation Adapter can attempt to verify that the ActiveX Reference you specified in an Automation Call is a reference to the correct type of object. A run-time error is generated when this option is enabled and you pass an ActiveX Reference to an incorrect type of object. Disable this option to improve execution speed.
- **Unload Unused ActiveX Servers After Execution**—When this option is enabled, the Automation Adapter requests that the operating system unload in-process (DLL) servers after every execution. The operating system unloads only servers that are no longer being used. Disable this option to improve execution speed.

Chapter 13—Process Models

Add the following entry to Table 13-3, Default Process Model Files:

Database.seq	Subsequences that log UUT results to a database.
--------------	--

Chapter 15—Run-Time Operator Interfaces

In the *LabVIEW Run-Time Operator Interface* section, steps 9 and 10 on page 15-5 are incorrect. Do not make a new `testexec.llb` for these steps.

Refer to the updated LabVIEW 5.1 instructions in the following locations to create run-time operator interfaces and a LabVIEW run-time server using LabVIEW 5.1.

- \OperatorInterfaces\NI\Lv\readme.doc
- \Examples\OperatorInterfaces\Simple LV\readme.txt
- \Components\NI\RuntimeServers\LabVIEW\readme.txt

Chapter 16—Distributing TestStand

This section describes the changes to the distribution of TestStand.

Distributing OLE DB Providers and ODBC Database Drivers

Add the following section below and at the same level as the *Using a Custom TestStand Engine Installation* section:

The TestStand engine installer does not have the capability to distribute OLE DB providers or ODBC database drivers, or to configure data source names in the ODBC Administrator. When you install TestStand on a target system, you must ensure that these database components are configured properly on the target system.

Customizing and Distributing a LabVIEW Run-Time Server

This section contains a description for LabVIEW 5.0 and earlier. The Application Builder has changed for LabVIEW 5.1. For LabVIEW 5.1 or later, replace steps 2-6 on page 16-13 with the following:

Select **Project»Build Application**. Press **Load** and select `TestStand\Components\User\RuntimeServers\LabVIEW\TestStandLVRTS.bld`. Press **Build** to build an executable.

For your information, the `TestStandLVRTS.bld` file contains the following settings:

- Under the Target tab, the Application name is `TestStandLVRTS.exe`.
- Under the Source Files tab, `TestStand-Runtime Server.vi` in `Server.llb` is enabled as the top level VI.
- Under the VI Settings tab, no changes were made.
- Under the App Settings tab, the Enable ActiveX Server is checked and the Server Name is `TestStandLVRTS`.
- Under the Installer tab, you have the option to make an installer. If you use the installer to distribute your ActiveX Server, you need to manually copy the `*.tlb` file and place it in the same directory as `TestStandLVRTS.exe`. The LabVIEW 5.1 installer does not copy this particular file. This will be corrected in a future version of LabVIEW.

Distributing the TestStand LabVIEW Run-Time Server

The *Distributing the TestStand LabVIEW Run-Time Server* section on page 16-14 states the following:

“If you want to manually register the ActiveX server in a LabVIEW run-time application, you can launch the executable with the `/Register` keyword on the command-line.”

For LabVIEW 5.1, this server registration command-line argument has changed to `/RegServer`.

Glossary

Add the following glossary terms:

- ADO—ActiveX Data Objects
- data link—Connection information for opening a data source, such as a database. A data link typically specifies the server on which the data resides, the database or file that contains the data, the user ID, and permissions to use when connecting to the data source.
- DBMS—Database Management Systems
- ODBC—Open Database Connectivity
- OLE DB—Object-linking and Embedding Database

Additional Changes

Any instance of *Login Name* within a dialog box has been renamed and will now be referred to as *User Name*. This affects the Edit User, New User, and Login dialog boxes.

Refer to the *TestStand User Manual Addendum* for more information on the database components included in TestStand 1.0.1. You can find the addendum at:

`\TestStand\Doc\TestStandDatabaseComponents.pdf`.



322519A-01

Aug99